
## MT8-COM3 Cable

The MT8-COM3 cable is designed to break out an MMI8000 Series RS485 COM1, COM3 RS232 COM3 ports to 3 separate connections. This allows the use of Standard DB9 Cables that utilize RS232/485 communications to a PLC.

Connect to MMI (HMI) COM1, COM3 [RS485] COM3 [RS232] DB9 Male	COM1 Port DB9 Male RS485 4 wire or 2 wire	COM3 Port DB9 Male RS485 2 wire	COM3 Port DB9 Male RS232
1 Rx- →	1 Rx-		
2 Rx+ →	2 Rx+		
3 Tx- →	3 Tx-		
4 Tx+ →	4 Tx+		
5 GND →	5 GND →	5 GND →	5 GND
6 Rx/Tx→		1 Rx/Tx	
7 TxD →			3 TxD
8 RxD →			2 RxD
9 Rx/Tx →		2 Rx/Tx	

## DI O DO 405/000 MTO COM4 Cable Ca

Observe markings on cable connectors for proper device connection.



Cable labeled with manufacturer's part number RZC004850

## CONNECTION TO A CONTROLLER

Cable Requirements

The MT8-COM1 is used as an adapter cable to the PLC's interface cable. Different cables are required for various devices. See the EasyBuilder8000 Help menu for Controller Specific Information Section for cable details.

- Restrict cable length to avoid communications problems due to weak signals. Recommended distance for RS485 is less than 4000' (1219m) Recommended distance for RS232 is less than 50' (15m)
- Shielded cable must be used for long lengths or cables run in an electrically noisy • environment.
- Do not run cables next to AC power lines or near sources of electrical noise. •
- Be sure that the cable ends have been inserted all of the way into mating connectors and are secure.

