

# SPARE PARTS

## Spare Parts

ORDER NO.	DESCRIPTION
Model 36120	Flex Cover
KRTBEZEL	Front panel bezel for KEPtrol R/T
BT2BEZEL	Front panel bezel for BT2
KEPTROLBEZEL	Front panel bezel for KEPtrol
MFCBEZEL	Front panel bezel for MASStrol
FLOWBEZEL	Front panel bezel for FLOWtrol
DPFCBEZEL	Front panel bezel for DPFC
MBBEZEL	Front panel bezel for MASSbatch
LVTBEZEL	Front panel bezel for LEVELtrol
KFCBEZEL	Front panel bezel for KEPtrol F/C
ST1LELCDFRONT	LCD Front panel assembly for SUPERtrol ILE
ST1LEVDFRONT	VFD Front panel assembly for SUPERtrol ILE
ST1LCDFRONT	LCD Front panel assembly for SUPERtrol I
ST1VDFRONT	VFD Front panel assembly for SUPERtrol I
ST2LCDFRONT	LCD Front panel assembly for SUPERtrol II
ST2VDFRONT	VFD Front panel assembly for SUPERtrol II
LT2LCDFRONT	LCD Front panel assembly for LEVELtrol II
LT2VDFRONT	VFD Front panel assembly for LEVELtrol II
KP8CASE	Case for KEPtrol
KRTCASE	Case for KEPtrol R/T
BT2CASE	Case for BT2
FIOCASE	Case for Flowtrol
MASSCASE	Case for MASStrol
DPFCCASE	Case for DPFC
ST1LEREAR	Rear Case for SUPERtrol ILE
ST1REAR	Rear Case for SUPERtrol I
ST2REAR	Rear Case for SUPERtrol II
LT2REAR	Rear Case for LEVELtrol II
Model 34503	Mounting Kit for: MRT series, INT69 series, BEACON series
STMOUNT	Mounting Kit for: ST1 series, ST2 series, LT2 series
TROLCLAMP	Mounting Kit (4 clamps & gasket)
*BATCHEMAINRT3L	KP8, KRT, BT2 Mainboard
*FLOWTROLMAIN	FLOWtrol Mainboard
*MASSMAINAC	MASStrol Mainboard, AC Power
*MASSMAINDC	MASStrol Mainboard, DC Power **
*DPFCMAINAC	DPFC Mainboard, AC Powered
*DPFCMAINDC	DPFC Mainboard, DC Powered **
*ST1LEMAINDC2	SUPERtrol ILE Mainboard, DC Powered, 2 Relays
*ST1LEMAINDC4	SUPERtrol ILE Mainboard, ** DC Powered, 4 Relays
*ST1LEMAINAC2	SUPERtrol ILE Mainboard, AC Powered, 2 Relays
*ST1LEMAINAC4	SUPERtrol ILE Mainboard, ** AC Powered, 4 Relays
*ST1MAINDC2	SUPERtrol I Mainboard, ** DC Powered, 2 Relays
*ST1MAINDC4	SUPERtrol I Mainboard, ** DC Powered, 4 Relays
*ST1MAINAC2	SUPERtrol I Mainboard, ** AC Powered, 2 Relays
*ST1MAINAC4	SUPERtrol I Mainboard, ** AC Powered, 4 Relays
*ST2MAINDC2	SUPERtrol II Mainboard, DC Powered, 2 Relays
*ST2MAINDC3	SUPERtrol II Mainboard, DC Powered, 3 Relays
*ST2MAINAC2	SUPERtrol II Mainboard, AC Powered, 2 Relays
*ST2MAINAC3	SUPERtrol II Mainboard, AC Powered, 3 Relays
*LT2MAINDC2	LEVELtrol II Mainboard, ** DC Powered, 2 Relays
*LT2MAINDC4	LEVELtrol II Mainboard, ** DC Powered, 4 Relays
*LT2MAINAC2	LEVELtrol II Mainboard, ** AC Powered, 2 Relays
*LT2MAINAC4	LEVELtrol II Mainboard, ** AC Powered, 4 Relays
KEPTROLDISP	KP8, KRT, BT2, FLO8 Display Board
MASSTROLDISP	MASStrol & DPFC Display Board

\*PROM sold separately (see \_Trol Program Chips at right)

\*\*Specify voltage when ordering

## MINITROL Input Chips

ORDER NO.	DESCRIPTION
EPLDMRTIN3	High Impedance input chip for Minitrol
EPLDMRTIN5	Up/down control input chip for Minitrol
EPLDMRTIN9	Quadrature input chip for Minitrol

## INT69 & MINITROL ACCESSORIES

ORDER NO.	DESCRIPTION
34235	Non Keyboard Front Panel
34234	Keyboard Front Panel

## BT2 & KRT Retrofit Boards

ORDER NO.	DESCRIPTION
3A/3B	High Imp. 3A & 3B Pulse Inputs
BA8ANA4-20MA	Input 5A; 4-20 mA Input
BA8ANA0-20MA	Input 5B; 0-20 mA Input
BA8ANA1-5V	Input 5C; 1-5 V Input
BA8ANA0-5V	Input 5D; 0-5 V Input
BA8ANA0-10V	Input 5E; 0-10 V Input
BATCHSQROOT	Input 6A; Square Law Input
*BA8IO7A4-20M	Input 7A; 4-20 mA In 4-20 mA Out
*BA8IO7B0-20M	Input 7B; 0-20 mA In 4-20 mA Out
*BA8IO7C1-5V	Input 7C; 1-5 V In 4-20 mA Out
*BA8IO7D0-5V	Input 7D; 0-5 V In 4-20 mA Out
*BA8IO7E0-10V	Input 7E; 0-10 V In 4-20 mA Out
BA8ANAOUT4-20	4-20mA out for 3A & 3B Inputs
BA8ANAOUT0-20	0-20mA out for 3A & 3B Inputs
BA8ANAOUT0-5	0-5V out for 3A & 3B Inputs
BA8ANAOUT0-10	0-10V out for 3A & 3B Inputs
BATCHRS232	RS 232 Interface Kit
BATCHRS422	RS 422 Interface Kit
MB8IN	MASSbatch Input
*MB8IN/OUT	MASSbatch Input w/ 4-20mA Out
* For Other Outputs:	
Add suffix X for 0-20 mA (i.e. BA8IO7A4-20MX, MB8IN/OUTX)	
Add suffix Y for 0-5 V out (i.e. BA8IO7A4-20MY, MB8IN/OUTY)	
Add suffix Z for 0-10 V out (i.e. BA8IO7A4-20MZ, MB8IN/OUTZ)	

## MASStrol & DPFC Retrofit Boards

ORDER NO.	DESCRIPTION
MASSRS232	RS 232 Interface Kit

## ...TROL Program Chips

ORDER NO.	DESCRIPTION
PROMBT2	PROM for BATCHtrol II
PROMBT216PT	PROM for BT2 w/16Pt
PROMFLO	PROM for FLOWtrol
PROMKFC	PROM for KEPtrol F/C
PROMKP8	PROM for KEPtrol
PROMKRT	PROM for KEPtrol R/T
PROMKRT16PT	PROM for KRT w/16Pt
PROMMFC	PROM for MASStrol(2 chips)
PROMRS	PROM for Trol RS422 & RS232
PROMRS422M	PROM for Trol RS422M
PROMMB	PROM for MASSbatch
PROMMB16PT	PROM for MASSbatch w/ 16Pt
PROMDPFC	PROM for DPFC (2 chips)
PROMLTR	PROM for LEVELtrol
PROMMS627	PROM for MS627 (2 chips)
PROMST1LE	PROM for SUPERtrol-ILE
PROMST1	PROM for SUPERtrol-I
PROMST2	PROM for SUPERtrol-II
PROMLT2	PROM for LEVELtrol-II
PROMST485	PROM for RS-485 option card for SUPERtrol
PROMPEELST2	PEEL PROM for SUPERtrol-II